

"INSTALLATION " "CUNDA BOOKCASE"

Ex6

1

A 	B 	C 	D 	E 	"AKSESUAR"
<p>Ax23 SCREW : 24x3 Ax18 SCREW : 8x40 Ax20 SCREW : 4x40 4MM DOWEL : 4x40 PLASTIC PROTECTOR : 4x40</p>					

RIGHT LEFT PLASTIC HOLDERS WILL BE PUT BY HAMMER . . .

Bx8

2

3

CONNECT THE BACK CROSS METALS AS SEEN IN THE PICTURE.

TAKE THE PRODUCT IN FLAT PLACE .

Ax16

4

**Cx2
Dx2**

5

ATTACH THE SHELVES..

MOUNT THE WALL.

Ax16

6

7

CONNECT THE REMAINING SHELVES.

Thank you for choosing us. Enjoy!

