

"ASSEMBLY"  
"KUZUY CABINET"

**A**

ALLEN SCREW 54 PCS

**B**

ALLIEN 1 PCS

**C**

SCREW 36 PCS

**D**

BRACKET 4 PCS

**E**

SCREW DOOR 10 PCS

**F**

RAIL 13 PCS

**G**

HANDLER 12 PCS

**H**

SCREW DOOR 10 PCS

**I**

SCREW DOOR 10 PCS

**O**

BRACKET 4 PCS

**J**

BRACKET 4 PCS

**P**

BRACKET 4 PCS

**S**

BRACKET 4 PCS

**T**

BRACKET 4 PCS

**U**

BRACKET 4 PCS

**V**

BRACKET 4 PCS

**Y**

BRACKET 4 PCS

**Z**

BRACKET 4 PCS

**"ACCESSORY"**

**1**

Combine parts 1 and 2

**2**

**Ax5**  
**Bx1**

INSTALL THE RAILS AS SHOWN

**3**

**Ax9**  
**Bx1**

**4**

**Cx20**

ASSEMBLE THE PARTS WITH THE ALLEN SCREW

**5**

**Dx4**  
**Bx8**

**6**

**Ex14**  
**Fx3**

ATTACH HINGES TO DOORS

**7**

**Ex6**  
**Gx3**  
**Hx3**

ASSEMBLE THE DRAWER FRONT AS IN THE FIGURE AND MOUNT IT TO THE CABINET

**MOUNT THE DOORS ON THE CABINET**

**THANKS...**