






ML 8

ASSEMBLY MANUAL

ACCESSORY LIST



A09 4x50  2x	A16  9x  2x	A12 5x35  20x	A41 35x50  6x
--	--	---	--

